

IX Series Integration with C.Cure® 9000

This integration allows the IX Series units to be viewed and utilized within the Software House[®] C•Cure[®] 9000 ver. 2.5, 2.6, 2.7, 2.8, 2.9, or 3.0 Access Control and Event Management platform. This makes event logging, visual display of device state, and triggering of external 3rd party functionality easier than ever. This document will cover what intercom events can trigger activities within C•Cure 9000 and how to enable the IX stations to send those events.

IX Series / Software House C•Cure 9000 diagram



Features

Device States and Events (which can be used to trigger 'Activities' within C•Cure 9000)

- Basic States
 - Offline (device has no connectivity with C•Cure 9000)
 - Online (device has connectivity with C•Cure 9000)
- Calling States/Events (indicates a call between IX stations, depending on priority level)
 - Normal Calling (Normal level call in process)
 - Priority Calling (Priority level call in process)
 - Urgent Calling (Urgent level call in process)

Communication States (states indicating established communication between IX stations, based on priority level)

- Normal Communicating (Normal level communication established)
- Priority Communicating (Priority level communication established)
- Urgent Communicating (Urgent level communication established)
- End Communication (Active call or communication terminated)
- Broadcast States/Events (states indicating a Paging Broadcast initiated, based on priority level)
 - Normal Broadcast (Normal level paging broadcast initiated)
 - Urgent Broadcast (Urgent level paging broadcast initiated)
 - End Broadcast (Broadcast end)
- Transfer States/Events (indicates a transfer between IX stations, depending on priority level)
 - Normal Transfer (Normal level transfer in process)
 - Priority Transfer (Priority level transfer in process)
 - Urgent Transfer (Urgent level transfer in process)
 - End Transfer (Active transfer terminated)
- Door Release Indication (event triggering a source and destination of door release action)
- Contact Change Events (event triggered at any change of input or output state)
- Health Check Events
 - Initialization Notice (IX station reporting boot up complete)
 - Communication Failure (IX station reporting an error condition)

For more details about the features and information above, please contact Technical Support.

Aiphone Corporation | www.aiphone.com | (800) 692-0200

ZAIPHONE

APPLICATION NOTE

	States	/Events			
Offline	InitializationNotice	NormalCall	EndBroadcast		
Online	NormalCommunicating	PriorityCall	NormalTransfer		
CommFail	PriorityCommunicating	UrgentCall	PriorityTransfer		
ContactChange	UrgentCommunicating	NormalBroadcast	UrgentTransfer		
DoorReleaseIndication	EndCommunication	UrgentBroadcast	EndTransfer		

Map View

- The IX Series integration allows any pre-configured map within the C•Cure 9000 to display intercom icons which can reflect the real-time status of any IX station, based on the device states listed above.
- Icons can be customized by the installer on a station-by-station basis, allowing complete customization of the IX stations on the map.

Journal View

- All device events and state changes are indicated within the C•Cure 9000 Journal for real-time visibility of activity without requiring a constant map display.
- All events and state changes are logged within the C•Cure 9000 Audit Log for complete traceability of all system activity.

Setup for IX Stations with C•Cure 9000

The following must be completed before the IX Series system will communicate with C•Cure 9000:

- Configure all stations properly per IX Support Tool Setting Manual included with the IX Series master station.
- Create and upload SIF settings for each IX-DV, IX-SS, and IX-MV7 station using the IX Support Tool.
- Create and upload the sif.ini file to each IX-DA, IX-BA, and IX-MV station using IX Support Tool.
- Fill out the SIF table for all other IX Series stations using IX Support Tool
- Ensure the Aiphone IX C•Cure 9000 Add-on driver is installed properly and included files are correctly configured.

The setup instructions that follow are specific to creating the .ini file and loading it to the IX Series stations. Refer to the IX Support Tool Setting Manual for complete setup information on the IX stations. Refer to the documentation provided with C•Cure 9000 for complete setup information on this product.

Setup for IX Stations

Creating SIF settings for IX stations

IX-DV, IX-SSA, IX-SS-2G, and IX-MV7 station will need to setup SIF events to communicate with the C•Cure 9000 system.

Important: The intercom system must be fully programmed and operational prior to creating SIF settings.

1A. Log in to the IX Series system using the IX Support Tool and select Station View.

1B. Expand the Function Settings tree on the left and select SIF.

- Function Settings
···· Door Release
Network Camera Integration
···· Paging Settings
···· Bathroom Call
Email
CGI
- SIF
··· Record

For more details about the features and information above, please contact Technical Support. Aiphone Corporation | www.aiphone.com | (800) 692-0200

1C. Choose the station to be edited from the Number drop down menu then click the Select button.

S	elect Station to Ec	dit
Туре:	All	~
Number:	0005	~
Previous	Select	Next

1D. Select the Enable radio button for SIF Functionality.

esie			
•OIF			
SIF Functionality	Enable	O Disable	
SIP URI Format	Enable	O Disable	

Scroll down to **SIF Settings**. Enter in the SIF settings as shown below. The IPv4 or IPv6 address will be the address of the CCURE server.

		IPv4	IPv6			
#	Program Type	1.0.0.1-223.255.255.254 or	::FF:0-FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFF	Destination Port	SSL	Connection
	0000-1111 🕈	hostname(1-64 alphanumeric characters 🔶	hostname(1-64 alphanumeric characters)	1024-65535 🕈	•	+
01	0010	192.168.1.100		10000	Disable ~	Socket 🗸
02					~	~
03					~	~

Scroll down to Transmission Trigger and select transmission triggers to send SIF events to the CCure 9000 server. (Only select transmission triggers that will be used as selecting every trigger will slow the system.)

fransmission Trigger																
Frank								Transr	nission							
Event	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16
Begin Outgoing Call																
Begin Communication (Source)																
End Communication	\checkmark															
Change contact																
Uniterror																
Periodical Transmission	\checkmark															
Initialization Notice																
End Outgoing Call	\checkmark															
Begin Incoming Call																
End Incoming Call																
Latch Reset	\checkmark															
Change Call Destination																
Call Failure																
Begin Incoming Page																
<																>

1E. Click **Update** to save the changes for the station then repeat the process for each station that will be associated with C•Cure 9000.



F. Upload settings to the IX stations (shown on page 5)



Creating SIF file (For IX-DA, IX-BA, and IX-MV only)

For the IX-DA, IX-BA, and IX-MV stations to communicate with C•Cure 9000, a sif.ini text file must be created and loaded to each station. The sif.ini file will tell these stations where to communicate (i.e. PC with C•Cure 9000). *Note: If the system does not include an IX-DA, IX-BA, or IX-MV station, skip this section and proceed to Upload Settings to Stations on page 5.*

Create the file using a text editor program (i.e. Notepad) and save it with a .ini extension. This text file content will vary depending on your settings.

sif.ini file

Program Type:	Range is between 0010 and 1111 (Binary).
Destination Address:	IP address for the PC running C-Cure 9000.
Destination Port:	Port number used to communicate with C-Cure 9000. The default port is 10000
SSL Y/N :	0 for non SSL transmission.
Example Text File:	0010,192.168.1.100,10000,0
	<u>File Edit Format View H</u> elp

0010,192.168.1.100,10000,0

Save the text file with a .ini extension (.ini must be typed manually) to a location on the PC being used for programming the IX Series stations. This file must be uploaded to each device associated with C-Cure 9000 using the instructions that follow.

Uploading SIF file (For IX-DA, IX-BA, and IX-MV only)

- 2A. Log in to the IX Series system using the IX Support Tool and select Station View.
- 2B. Expand the Function Settings tree on the left and select SIF.

⊡ F	unction Settings
	- Door Release
	Network Camera Integration
	Paging Settings
	Bathroom Call
	Email
	CGI
	SIF
	Record

2C. Choose the station to be edited from the Number drop down menu then click the Select button.

S	elect Station to Edit
Туре:	All
Number:	100 👻
Draviaua	100
Flevious	101
	200
	201



Uploading SIF file (For IX-DA, IX-BA, and IX-MV only)

2D. Select the Enable radio button for SIF Integration.

esie			
001			
SIF Functionality	Enable	O Disable	
-			
SIP LIBI Format	Enable	Disable	
on orthoniat		Disable	

Scroll down to SIF File Management. Click **Browse** under SIF Communication Settings to browse to where the sif.ini file is saved and click **Upload** to send to station.

SIF File Management	
SIF Communication Settings (sif.ini)
	Browse Upload
	Download
	To upload, station must be associated.

2E. Click Update to save the changes for the station then repeat the process for each station that will be associated with C•Cure 9000.



Upload Settings to Stations

F. After completing steps C, D, and E for each station, upload the changes. Click **File**, **Upload Settings to Station**. Select the stations to upload to and click **Settings**.

ings.	Text in red are required settings	ist	Station				
			Station L				
		Status	Station Type	Location	Name	Number	Select
			IX-MV7-*		Shipping Office	0001	\square
		-	IX-DV, IX-DVF(-*)		Gate Upper Entry	0002	\square
		-	IX-DV, IX-DVF(-*)		Gate Lower Entry	0003	
		-	IX-DV, IX-DVF(-*)		Gate Upper Exit	0004	
		-	IX-DV, IX-DVF(-*)		Gate Lower Exit	0005	
>							
					ie:	ation by Typ	lect St
		lect	Unse	Select	~		I
					w.	ation by Tyr	<

Upload the settings file to each station to be associated with C•Cure 9000.

! The IX Support Tool or web browser interface can be used to upload the program file to each station. Loading via the IX Support Tool in Station View is shown in these instructions.